Please be advised that the OPENING DIMENSION is going to give us the most accurate measurement for that part. We CAN make it MTD (made to dimension) however we won't be able to guarantee that it will fit correctly when the measurement is taken off of the gasket itself.

The door opening dimensions can be measured by measuring the distance between the inside point at the jamb from one side of the opening to the other.

We have two versions of the SNAP-IN GASKET. One is for our FRP Doors and has 3-darts. The other is a single-dart SNAP-IN GASKET. Please see attached photo. The one on the left is the FRP and the one in the center is the single-dart snap in. The one on the right is our SCREW-ON GASKET.


Gasket



HOW TO MEASURE YOUR DOOR OPENING


DOOR OPENING WIDTH

Measure the distance between the inside point at the jamb from one side of the opening to the other.



DOOR OPENING HEIGHT

Measure the distance from the floor to the underside of the top jamb opening.



DOOR HINGE LOCATION

To dertemine if the door is RIGHT or LEFT HINGED, simply look at the door from the outside – as if you were going into the walk-in – to see which side the hinges are on.